





**EOSC433:**  
**Geotechnical Engineering**  
**Practice & Design**

**Lecture 8:**  
**Stress Analysis**  
**around Underground**  
**Openings**



**Flin Flon Mining Belt**


Since 1927, more than 29 mines have been developed in the Flin Flon Greenstone belt in the Canadian Shield, with continuous production of zinc, copper, silver, and gold since 1930.



## Case History: Trout Lake Mine



	Tonnes	Au (g/t)	Ag (g/t)	Cu (%)	Zn (%)
<b>Trout Lake</b>					
Proven	1,433,000	1.0	11.1	1.4	4.7
Probable	1,058,000	1.7	20.5	2.5	4.0



The Trout Lake Cu-Zn sulphide deposit was discovered in 1976, with mining beginning in 1982. The deposit is a VMS-type deposit that involves two ore zones 500 m apart, which reach depths exceeding 1200 m.




3 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Flin Flon Mining Belt



In a historic mining centre like Flin Flon, the life of the town is dependent on the ability to mine new and deeper reserves to feed the mill and keep the smelter running.




4 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Case History: Trout Lake Mine



Initial mining was carried out by ramping down to the deposit and mining it at relatively shallow depths through sub-level stopeing. To what depths, though, will mining be economical?



Brady & Brown (2006)





5 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Case History: Trout Lake Mine



Trouble: Ground control, dilution and pillar stability problems encountered at 400m depth.




6 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)


## Case History: Trout Lake Mine



## Case History: Trout Lake Mine Sill Pillar




## Case History: Trout Lake Mine















## Stress-Controlled Instability Mechanisms

Structurally-controlled instabilities are generally driven by gravity (i.e., unidirectional force). Stress-controlled instabilities, however, are not activated by a single force, but by a tensor with six independent components. Hence, the manifestations of stress-controlled instability are more variable and complex than those of structurally-controlled failures.



## Stress-Controlled Instability Mechanisms

	Massive (RMR > 75)	Moderately Fractured (50 > RMR > 75)	Highly Fractured (RMR < 50)	
Low In-Situ Stress ( $\sigma_1 / \sigma_3 < 0.15$ )	 Linear elastic response.	 Falling or sliding of blocks and wedges.	 Unravelling of blocks from the excavation surface.	Low Mining-Induced Stress $\sigma_{max}/\sigma_c < 0.4 \text{ to } 0.1$
Intermediate In-Situ Stress ( $0.15 > \sigma_1 / \sigma_3 > 0.4$ )	 Brittle failure adjacent to excavation boundary.	 Localized brittle failure of intact rock and movement of blocks.	 Localized brittle failure of intact rock and unravelling along discontinuities.	Intermediate Induced Stress $0.4 \text{ to } 0.1 < \sigma_{max}/\sigma_c < 1.15 \text{ to } 0.1$
High In-Situ Stress ( $\sigma_1 / \sigma_3 > 0.4$ )	 Failure zone around the excavation.	 Brittle failure of intact rock around the excavation and movement of blocks.	 Squeezing and swelling rocks. Elastic-plastic continuum.	High Mining-Induced Stress $\sigma_{max}/\sigma_c > 1.15 \text{ to } 0.1$

Kaiser et al. (2000)



11 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stress-Controlled Instability Mechanisms

Although the fundamental complexity of the nature of stress has to be fully considered in the design of an underground excavation, the problem can be initially simplified through the assumptions of continuous, homogeneous, isotropic, linear elastic behaviour (CHILE).

**CHILE: Continuous, Homogeneous, Isotropic, Linear Elastic**

**DIANE: Discontinuous, Inhomogeneous, Anisotropic, Non-Elastic**

The engineering question is whether a solution based on the CHILE assumption are of any assistance in design. In fact though, many CHILE-based solutions have been used successfully, especially in those excavations at depth where high stresses have closed the fractures and the rock mass is relatively homogeneous and isotropic. However, in near-surface excavations, where the rock stresses are lower, the fractures more frequent, and the rock mass more disturbed and weathered, there is more concern about the validity of the CHILE model.



12 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stress-Controlled Instability Mechanisms

A stress analysis begins with a knowledge of the **magnitudes and directions of the *in situ* stresses** in the region of the excavation. This allows for the calculation of the excavation disturbed or **induced stresses**.

Brady & Brown (2006)



There exists several close form solutions for the induced stresses around circular and elliptical openings (and complex variable techniques extend these to many smooth, symmetrical geometries), and with **numerical analysis techniques** the values of the induced stresses can be determined accurately for any three-dimensional excavation geometry.




13 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stresses & Displacements - Circular Excavations

The **Kirsch equations** are a set of closed-form solutions, derived from the theory of **elasticity**, used to calculate the stresses and displacements around a **circular excavation**.



$$\sigma_{rr} = \frac{p}{2} \left[ (1+K) \left( 1 - \frac{a^2}{r^2} \right) - (1-K) \left( 1 - 4\frac{a^2}{r^2} + \frac{3a^4}{r^4} \right) \cos 2\theta \right]$$

$$\sigma_{\theta\theta} = \frac{p}{2} \left[ (1+K) \left( 1 + \frac{a^2}{r^2} \right) + (1-K) \left( 1 + \frac{3a^4}{r^4} \right) \cos 2\theta \right]$$

$$\sigma_{r\theta} = \frac{p}{2} \left[ (1-K) \left( 1 + \frac{2a^2}{r^2} - \frac{3a^4}{r^4} \right) \sin 2\theta \right]$$

$$u_r = -\frac{pa^2}{4Gr} \left[ (1+K) - (1-K) \left\{ 4(1-\nu) - \frac{a^2}{r^2} \right\} \cos 2\theta \right]$$

$$u_\theta = -\frac{pa^2}{4Gr} \left[ (1-K) \left\{ 2(1-2\nu) + \frac{a^2}{r^2} \right\} \sin 2\theta \right]$$

Brady & Brown (2006)

**Stress ratio:**  
 $k = \sigma_h / \sigma_v$



14 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stresses & Displacements - Circular Excavations


From these equations we can see that the stresses on the boundary (i.e. when  $r = a$ ) are given by:

$$\sigma_{\theta\theta} = p[(1+k) + 2(1-k)\cos 2\theta]$$

$$\sigma_{rr} = 0$$

$$\tau_{r\theta} = 0$$

Note that the radial stresses are zero because there is no internal pressure, and the shear stresses must be zero at a traction-free boundary.



15 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #1: Stresses around a Circular Opening

Q. At a depth of 750 m, a 10-m diameter circular tunnel is driven in rock having a unit weight of 26 kN/m<sup>3</sup> and uniaxial compressive and tensile strengths of 80.0 MPa and 3.0 MPa, respectively. Will the strength of the rock on the tunnel boundary be exceeded if:

(a)  $k=0.3$ , (b)  $k=2.0$ ?



Harrison & Hudson (2000)

A. Since the tunnel has neither a support pressure nor an internal pressure applied to it, the local stresses at the boundary have  $\sigma_3 = \sigma_r = 0$  and  $\sigma_1 = \sigma_\theta$ . The Kirsch solution for the circumferential stress is:

$$\sigma_\theta = \frac{1}{2}\sigma_v \left[ (1+k) \left( 1 + \frac{a^2}{r^2} \right) + (1-k) \left( 1 + 3\frac{a^4}{r^4} \right) \cos 2\theta \right]$$

For a location on the tunnel boundary (i.e.  $a = r$ ), this simplifies to:

$$\sigma_\theta = \sigma_v [(1+k) + 2(1-k)\cos 2\theta]$$



16 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)



## Example #1: Stresses around a Circular Opening

Q. Circular tunnel: 750 m deep, 10m diameter,  $\gamma_{\text{rock}} = 26$  kN/m<sup>3</sup>,  $\sigma_{\text{UCS}} = 80.0$  MPa,  $\sigma_{\text{T}} = 3.0$  MPa. Will the strength of the rock on the tunnel boundary be reached if: (a)  $k=0.3$ , and (b)  $k=2.0$ ?



A. We assume that the vertical stress is caused by the weight of the overburden, in which case we have:

$$\sigma_v = \gamma z = 0.026 \times 750 = 19.5 \text{ MPa}$$

The extreme values of induced stress occur at positions aligned with the principal *in situ* stresses, and so in order to compute the stress induced in the crown and invert (i.e. roof and floor) we use  $\theta = 90^\circ$ , and for the sidewalls we use  $\theta = 0^\circ$ .




17 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #1: Stresses around a Circular Opening

Q. Circular tunnel: 750 m deep, 10m diameter,  $\gamma_{\text{rock}} = 26$  kN/m<sup>3</sup>,  $\sigma_{\text{UCS}} = 80.0$  MPa,  $\sigma_{\text{T}} = 3.0$  MPa. Will the strength of the rock on the tunnel boundary be reached if: (a)  $k=0.3$ , and (b)  $k=2.0$ ?



A. For  $k=0.3$ :

Crown and invert ( $\theta = 90^\circ$ ),  $\sigma_\theta = -1.95$  MPa (i.e. tensile)  
 Sidewalls ( $\theta = 0^\circ$ ),  $\sigma_\theta = 52.7$  MPa

For  $k=2.0$ :

Crown and invert ( $\theta = 90^\circ$ ),  $\sigma_\theta = 97.5$  MPa  
 Sidewalls ( $\theta = 0^\circ$ ),  $\sigma_\theta = 19.5$  MPa

compressive strength is exceeded




18 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stress and Failure Criterion




The key is that the failure criterion is compared to the stresses and is not part of the calculation!!

We'll see this is different when similar relationships based on Mohr-Coulomb and Hoek-Brown are incorporated into stress-strain constitutive relationships.

Brady & Brown (2006)



## Orientation of $\sigma_1$ & Induced Stresses



Potential Ground Control Issues:

Relaxation = wedge failures  
Concentration = spalling


Stresses can be visualized as flowing around the excavation periphery in the direction of the major principle stress ( $\sigma_1$ ). Where they diverge, relaxation occurs; where they converge, stress increases occur.



## Conservation of Load

Another concept that can be elegantly demonstrated from the Kirsch equations is the principle of conservation of load.

... principle of conservation of load before and after excavation. The sketches show how the distribution of vertical stresses across a horizontal plane changes.



Hudson & Harrison (1997)




21 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)


## Stresses Away from Opening



$$\sigma_r = \frac{1}{2} p_z \left\{ (1+k) \left( 1 - \frac{a^2}{r^2} \right) - (1-k) \left( 1 - 4 \frac{a^2}{r^2} + 3 \frac{a^4}{r^4} \right) \cos 2\theta \right\}$$

$$\sigma_\theta = \frac{1}{2} p_z \left\{ (1+k) \left( 1 + \frac{a^2}{r^2} \right) + (1-k) \left( 1 + 3 \frac{a^4}{r^4} \right) \cos 2\theta \right\}$$

$$\tau_{r\theta} = \frac{1}{2} p_z \left\{ (1-k) \left( 1 + 2 \frac{a^2}{r^2} - 3 \frac{a^4}{r^4} \right) \sin 2\theta \right\}$$



22 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Zone of Influence

The concept of influence is important in excavation design, since the presence of a neighbouring opening may provide a significant disturbance to the near-field stresses to the point of causing failure.

... (a) axisymmetric stress distribution around a circular opening in a hydrostatic stress field; (b) circular openings in a hydrostatic stress field, effectively isolated by virtue of their exclusion from each other's zone of influence.



Brady & Brown (2006)




23 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Zone of Influence



Brady & Brown (2006)

... illustration of the effect of contiguous openings of different dimensions. The zone of influence of excavation I includes excavation II, but the converse does not apply.




24 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stresses Around Elliptical Openings



The stresses around **elliptical openings** can be treated in an analogous way to that just presented for circular openings. There is much **greater utility** associated with the solution for elliptical openings than circular openings, because these can provide a first approximation to a wide range of **engineering geometries**, especially openings with high width/height ratios (e.g. mine stopes, power house caverns, etc.).

From a design point of view, the effects of changing either the **orientation within the stress field** or the **aspect ratio** of such elliptical openings can be studied to optimize stability.




25 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stresses Around Elliptical Openings

Assuming **isotropic rock conditions**, an elliptical opening is completely characterized by two parameters: **aspect ratio** (major to minor axis) which is the eccentricity of the ellipse; and **orientation** with respect to the principle stresses. The position on the boundary, with reference to the x-axis, is given by the angle  $\chi$ .



Hudson & Harrison (1997)




26 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stresses Around Elliptical Openings

It is instructive to consider the maximum and minimum values of the stress concentrations around the ellipse for the geometry of an ellipse aligned with the principal stresses. It can be easily established that the extremes of stress concentration occur at the ends of the major and minor axes.



Hudson & Harrison (1997)



27 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #2: Stresses around an Elliptical Opening

**Q.** A gold-bearing quartz vein, 2 m thick and dipping 90°, is to be exploited by a small cut-and-fill stope operation. The mining is to take place at a depth of 800 m, and the average unit weight of the granite host rock above this level is 29 kN/m<sup>3</sup>. The strike of the vein is parallel to the intermediate stress, and the major principal stress is horizontal with a magnitude of 37.0 MPa. The uniaxial compressive strength of the vein material is 218 MPa, and the tensile strength of the host rock is -5 MPa. What is the maximum permissible stope height before failure occurs.

**A.** We can assume that, in 2-D cross-section, the stresses induced in the sidewalls (tensile) and the crown (compressive) of the stope can be approximated using the equations for an elliptical excavation.

$$\frac{\sigma_{\text{sidewall}}}{\sigma_{\text{vertical}}} = 1 - k + 2\left(\frac{w}{h}\right) \qquad \frac{\sigma_{\text{crown}}}{\sigma_{\text{vertical}}} = k - 1 + k\sqrt{\frac{2h}{\rho_{\text{crown}}}} = k - 1 + 2k\sqrt{\frac{h}{w}}$$




28 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #2: Stresses around an Elliptical Opening

Q. Gold-bearing quartz vein: 2 m thick, dipping 90°. The mining stope is 800 m deep,  $\gamma = 29 \text{ kN/m}^3$ , strike parallel to  $\sigma_2$ ,  $\sigma_1 = 37.0 \text{ MPa}$  and is horizontal,  $\sigma_{UCS}(\text{vein}) = 218 \text{ MPa}$ ,  $T_o(\text{host rock}) = -5 \text{ MPa}$ . What is the maximum permissible stope height before failure occurs.



Harrison & Hudson (2000)

A. Rearranging the given equations, we can solve for the height of the excavation as the minimum of:

$$h = \frac{2w}{\frac{\sigma_{\text{sidewall}}}{\sigma_{\text{vertical}}} + k - 1} \quad \text{or} \quad h = \frac{w}{4k^2} \left( \frac{\sigma_{\text{crown}}}{\sigma_{\text{vertical}}} + 1 - k \right)^2$$

The maximum stress that can be sustained by the crown and the sidewall are 218 and -5 MPa, respectively. Note that the sidewall stress is negative because this represents the tensile strength.




29 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #2: Stresses around an Elliptical Opening

Q. Gold-bearing quartz vein: 2 m thick, dipping 90°. The mining stope is 800 m deep,  $\gamma = 29 \text{ kN/m}^3$ , strike parallel to  $\sigma_2$ ,  $\sigma_1 = 37.0 \text{ MPa}$  and is horizontal,  $\sigma_{UCS}(\text{vein}) = 218 \text{ MPa}$ ,  $T_o(\text{host rock}) = -5 \text{ MPa}$ . What is the maximum permissible stope height before failure occurs.



Harrison & Hudson (2000)

A. The vertical stress is:

$$\sigma_{\text{vertical}} = \gamma \cdot z = 0.029 \times 800 = 23.2 \text{ MPa}$$

and hence the ratio of horizontal to vertical stress is:

$$k = \frac{37.0}{23.2} = 1.59.$$




30 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Example #2: Stresses around an Elliptical Opening

Q. Gold-bearing quartz vein: 2 m thick, dipping 90°. The mining stope is 800 m deep,  $\gamma = 29 \text{ kN/m}^3$ , strike parallel to  $\sigma_2$ ,  $\sigma_1 = 37.0 \text{ MPa}$  and is horizontal,  $\sigma_{UCS}(\text{vein}) = 218 \text{ MPa}$ ,  $T_o(\text{host rock}) = -5 \text{ MPa}$ . What is the maximum permissible stope height before failure occurs.



Harrison & Hudson (2000)

A. The maximal height of a stope such that the compressive strength of the rock in the crown is not exceeded is given by:

$$h = \frac{w}{4k^2} \left( \frac{\sigma_{\text{crown}}}{\sigma_{\text{vertical}}} + 1 - k \right)^2 = \frac{2}{4 \times 1.59^2} \left( \frac{218}{23.2} + 1 - 1.59 \right)^2 = 15.3 \text{ m.}$$

The maximal height of a stope such that the tensile strength of the rock in the sidewall is not exceeded is given by:

$$h = \frac{2w}{\frac{\sigma_{\text{sidewall}}}{\sigma_{\text{vertical}}} + k - 1} = \frac{2 \times 2}{\frac{-5}{23.2} + 1.59 - 1} = 10.7 \text{ m.}$$

Thus we see that sidewall failure is the limiting condition in the stope design.




31 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stress Analysis - Numerical Modelling

Many underground excavations are irregular in shape and are frequently grouped close to other excavations. These problems require the use of numerical techniques.



Eberhardt et al. (1997)



32 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)




## Numerical Modelling

Numerical methods of stress and deformation analysis fall into two categories:


### Integral Methods

- incl. boundary-element method
- only problem boundary is defined & discretized
- Pro: more computationally efficient
- Con: restricted to elastic analyses



### Differential Methods

- incl. finite-element/-difference & distinct-element methods
- problem domain is defined & discretized
- Pro: non-linear & heterogeneous material properties accommodated
- Con: longer solution run times




33 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Boundary-Element & Stress Analyses

The Boundary Element Method (BEM) is generally favoured for stress analyses involving multiple excavations with complex 3-D geometries (e.g. those frequently encountered in underground mine design). The irregular shape of the orebodies and staged nature of mining, makes the ease of mesh generation and computational efficiency afforded by the BEM highly advantageous.



Complex 3-D geometries: It's easier to generate a mesh over a surface than through a volume

Eberhardt et al. (1997)

### Commercial Software:

Examine3D (Rocscience) - <http://www.rocscience.com/>  
 Map3D (Mine Modelling Pty Ltd.) - <http://www.map3d.com/>  
 BEFE (Computer Software & Services - CSS) - <http://members.chello.at/sylvia.beer/>  
 GPBEST (Best Corp.) - <http://www.gpbest.com/>  
 BEASY (Beasy Group) - <http://www.beasy.com/>




34 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Boundary-Element & Stress Analyses

In performing an analysis, the boundary of the excavation is divided into elements and the interior of the rock mass is represented mathematically as an infinite continuum. The solution works to find a set of approximate stresses which satisfy prescribed boundary conditions, and then uses these to calculate the stresses and displacements in the rock mass.



### What to Know:

- Computational method of solving linear partial differential equations which have been formulated as integral equations (i.e. in boundary integral form).
- Key advantage is the reduction of the model dimension by one, providing simpler mesh generation & input data preparation, and greater computational efficiency.
- Key disadvantage is the required assumption of homogeneous linear elastic material behaviour; plasticity and heterogeneity negate the method's intrinsic simplicity.
- Common applications include stress analysis of underground excavations, soil-structure interactions, brittle fracturing processes, dynamic problems, groundwater flow and coupled H-M & T-H-M problems.




35 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Boundary-Element & Stress Analysis




36 of 45


Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Stress Analysis & Failure




## In-Situ Stresses - Canadian Shield




## Case History: Trout Lake Mine Stress Analysis

Reschke & Romanowski (1993)



Empirical analysis based on performance of stopes backs in the Flin Flon deposits, although useful, may be limited in its applicability if the database is populated with cases at shallower depths (i.e. lower stresses).

Eberhardt et al. (1997)



2-D and 3-D stress analyses of Trout Lake stopes.




39 of 45

Erik Eberhardt - UBC Geological Engineering


EOSC 433 (2017)

## Test Stope at Depth



Stability charts indicate that stopes at 1000m depth will require cable bolting. Without it, significant hangingwall dilution (40%) would be expected.

deGraaf et al. (1993)




40 of 45

Erik Eberhardt - UBC Geological Engineering



EOSC 433 (2017)

## Test Stope at Depth

deGraaf et al. (1993)



Smart cable monitoring of cablebolt loading in hangingwall.




41 of 45

Erik Eberhardt - UBC Geological Engineering


EOSC 433 (2017)

## Case History: Trout Lake Mine Stress Analysis


Eberhardt et al. (1997)



3-D boundary element analyses help to examine the stress interactions between neighbouring stopes.



Computed stresses can then be compared against estimated rock mass strengths to assess pillar stability.




42 of 45

Erik Eberhardt - UBC Geological Engineering


EOSC 433 (2017)

## Sill Pillar Thickness



Eberhardt et al. (1997)

## Elastic Sill Pillar Analysis



## Elasto-Plastic Sill Pillar Analysis



43 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Sill Pillar Value

Pillars represent either temporary or permanent sterilisation of a fully proven and developed ore reserve. Calculate the value of the Trout Lake sill pillar, using the spreadsheet provided and the following assumptions.

- Production grades: 2.18% Cu, 3.65% Zn, 1.28g/t Au, and 13.53g/t Ag.
- Operating costs: \$42/tonne.
- Sill pillar footprint: 2000 m<sup>2</sup>



44 of 45

Erik Eberhardt - UBC Geological Engineering

EOSC 433 (2017)

## Lecture References

Brady, BHG & Brown, ET (2006). *Rock Mechanics for Underground Mining*, (3<sup>rd</sup> Edition). Chapman & Hall: London.

DeGraaf, PJH, Hyett, AJ, Lausch, P, Bawden, WF & Yao, M (1999). Hudson Bay Mining and Smelting Co.'s field trials using 'SMART' technology - successful ground support design through in situ cable bolt performance evaluation. In *Proceedings of the 101st Annual General Meeting of CIM, Calgary*.

Eberhardt, E, Stead, D, Reeves, MJ & Connors, C (1997). Design of tabular excavations in foliated rock: An integrated numerical modelling approach. *Geotechnical and Geological Engineering* 15 (1): 47-85.

Harrison, JP & Hudson, JA (2000). *Engineering Rock Mechanics - Part 2: Illustrative Worked Examples*. Elsevier Science: Oxford.

Heidbach, O, Tingay, M, Barth, A, Reinecker, J, Kurfeß, D & Müller, B (2008). The World Stress Map database release 2008. doi:10.1594/GFZ.WSM.Rel2008.

Hudson, JA & Harrison, JP (1997). *Engineering Rock Mechanics - An Introduction to the Principles*. Elsevier Science: Oxford.

Kaiser, PK, Diederichs, MS, Martin, D, Sharpe, J & Steiner, W (2000). Underground works in hard rock tunnelling and mining. In *GeoEng2000, Melbourne*. Technomic Publishing Company: Lancaster, pp. 841-926.

Reschke, AE & Romanowski, J (1993). The success and limitations of Mathews analysis for open stope design at HBMS, Flin Flon operations. In *95th CIM Annual General Meeting, Calgary*. Paper #136, 13 pp.

